

scoop up oil contaminated material and dispose of

REAF RICHARDSON- 9/22/22. Full replacement of culvert. Fire burned out culvert and now the water from running stream has been diverted. Could lead to watershed and railroad below issues. Full replacement needed. Excavator with 6-way blade to dig new culvert. Compactor needed. // REAF ALLEN 09/27/22 Road to be decommissioned. Culvert will not be replaced. Remove rest of culvert with excavator. Dig out new stream bed. match the slope of stream. Add rock to bottom of new channel. clear any debris

Pull back berm, excavator bucket recommended to avoid additional sediment delivery/ disturbance to eagle creek drainage. Seed and mulch REAF ALLEN

Use excavator to clean debris pile out of ditch and scatter onto other side of 43° 41.262' N

Clear culvert basin, pull out debris from and around culvert, clear ditch of debris- Geertsen 8/30 // REAF ALLEN 09/27/22 Culvert on South side of road has been flagged and labeled. Clear chips and debris away from culvert and out of streambed

43° 39.189' N 122° 07.452' W

43° 41.142' N 122° 11.977' W

122° 10.085' W

122° 11.496' W

122° 10.366' W

43° 39.825' N 122° 12.617' W

43° 40.841' N 122° 10.348' W

43° 40.345' N 122° 10.036' W

43° 40.105′ N

43° 40.387′ N

Adam 10.5 Burned over. Remove Mark3 pumps, gas canisters, hose and sprinklers exist on site

READ ALLEN 09/22/22 Level out tire tracks. Seed and mulch.

REAF GRANT 10/7: site reestablished after slopover, will need additional repair. Remove lining and ensure no scour at culvert below. Collect fish screen REAF BERG 9/27.

scoop up contaminated material

map exported at 10/20/2022 2202 hrs